

Pinbelegung

SX1280

RESET -> PA2

BUSY -> PA1

CS -> PA4

SCLK -> PA5

MISO -> PA6

MOSI -> PA7

DIO1 -> PA0

DIO2 -> PC3

DIO3 -> PC2

SKY66112

CTX -> PB2

CRX -> PB13

CPS -> PE8

ANT_SEL -> PB14

Revision #4

Created 31 October 2025 15:23:53 by Max Känner

Updated 31 October 2025 15:29:06 by Max Känner